

# Good News!

In the time since we printed the Nero™ 5 Quick Start Guide we've added more features to your Nero™ 5 pump! Below are some changes to the button press functionality.

---

## Feed Mode

The Nero™ will spin very slowly for 10 minutes (default setting) and then resume it's set mode.

1. Hold the button on the Driver for **2-5 seconds** until the LED blinks white. The button LED will blink white while in feed mode.

## All Off

All connected Nero™ pumps will stop.

1. Hold the button on the Driver for **6+ seconds** until the LED fades out. The button LED will pulse white while pumps are off.

### To resume:

1. Press the button once.

Continued on the back...

## Soft Reset

A soft reset restarts the device but retains the schedule and settings. To perform a soft reset:

1. Unplug from power.
2. Reapply power.

## Connected Reset

A connected reset restarts the device and removes your schedule and settings, but keeps the connection settings. To perform a connected reset:

1. Unplug from power.
2. Press and hold button.
3. Reapply power and wait for the LED to blink green.
4. Release button.

## Factory Reset

A factory reset restarts the device and removes your settings and schedule data, returning it to factory defaults.

Contact Support or visit [support.aquillumination.com](https://support.aquillumination.com) for troubleshooting before performing a factory reset.

### To perform a factory reset:

1. Unplug from power.
2. Press and hold button.
3. Reapply power and wait for the LED to blink red.
4. Release button.

